

RADONAWAY RSA1



INSTRUCTION SUPPLEMENT

P/N 28535



This document provides the purchaser with additional information to be utilized during installation of RadonAway's RSA1 radon system alarm.

DIRECT PIPE MOUNTING HORIZONTAL & VERTICAL PIPE

Pipe Hole Size: RadonAway recommends using a 9/16" drill bit in lieu of a 5/8" drill bit to provide a tighter fit for the alarm adaptor when mounted to the pipe.

Pipe Adaptor Installation: When attaching the pipe adaptor for the alarm, first make sure the pipe is clean, dry and free of any debris. Peel back the protective film on the mounting tape and insert the assembled alarm/bracket assembly into the drilled hole, making sure it is level, and firmly press in place to seat mounting tape.

NOTE: ADAPTOR MUST BE PRESSED FIRMLY AGAINST PIPE FOR 30 SECONDS TO ENSURE THAT THE 3M TAPE BONDS TO THE PIPE AND BRACKET SURFACES.